



Electrical data			
Ratings per IEC/EN		Ex information	
Nominal voltage (III/3)	800 V	Rated current (Ex e II)	20 A
Rated current	25 A		

Physical data		
Width	45.2 mm / 1.78 inches	
Height	4.1 mm / 0.161 inches	
Depth	19 mm / 0.748 inches	
Jumper assignment	1-2-3-4-5-6-7-8-9	

Material data	
Note (material data)	Information on material appointions can be found have
	Information on material specifications can be found here
Color	blue
Fire load	0.032 MJ
Weight	4.4 g


Commercial data	
eCl@ss 10.0	27-14-11-40
eCl@ss 9.0	27-14-11-40
ETIM 8.0	EC000489
ETIM 7.0	EC000489
PU (SPU)	25 pcs
Packaging type	Bag
Country of origin	DE
GTIN	4055143690478
Customs tariff number	85366990990

Data Sheet | Item Number: 2002-409/000-006

https://www.wago.com/2002-409/000-006

Environmental Product Compliance

RoHS Compliance Status





Approvals / Certificates Declarations of conformity and manufacturer's declarations Image: Conformity and manufacturer's declarations Approval Standard Certificate Name Railway WAGO GmbH & Co. KG Railway Ready

Downloads
Environmental Product Compliance
Compliance Search
Environmental Product Compliance 2002-409/000-006

Documentation

Bid Text			
2002-409/000-006	19.02.2019	xml 2.52 KB	$\underline{\downarrow}$
2002-409/000-006	27.04.2017	doc 24.00 KB	\downarrow

CAD/CAE-Data

CAD data	
2D/3D Models 2002-409/000-006	\downarrow

CAE data	
EPLAN Data Portal 2002-409/000-006	$\underline{\checkmark}$
WSCAD Universe 2002-409/000-006	$\underline{\checkmark}$
ZUKEN Portal 2002-409/000-006	$\underline{\checkmark}$

Data Sheet | Item Number: 2002-409/000-006 https://www.wago.com/2002-409/000-006

N⁄AGO

Installation Notes

Commoning



Insert push-in type jumper bar and push down until it hits backstop.



Removing a push-in type jumper bar: Insert the operating tool between the jumper and partition wall of the dual jumper slots, then lift up the jumper. Place the operating tool in the center of jumpers for up to five contacts (see above), or alternately on both sides for jumpers with more than five contacts.

Commoning





Custom jumpers are created by breaking and removing jumper contacts (2000, 2001, 2002, 2004 Series).

Marking with a felt-tip pen.

Commoning




For example, colored push-in type jumper bars are used with sensor terminal blocks.

Commoning



Stepping down via push-in type jumper bar.



Stepping down via push-in type jumper bar:

Commoning via closed terminal side with end plate allows jumpering over two cross-section sizes, e.g., from 16 mm² (6 AWG) to 6 mm² (10 AWG) or from 6 mm² (10 AWG) to 2.5 mm² (14 AWG) (see illustration above).



Stepping down via push-in type jumper bar:

Commoning via open terminal side with end plate allows jumpering over two cross-section sizes for 16 mm² (6 AWG) and 10 mm² (8 AWG) and one cross-section size for 6/4/2.5 mm² (10/12/14 AWG). An example: from 16 mm² (6 AWG) to 6 mm² (10 AWG) (see illustration above) or from 10 mm² (8 AWG) to 4 mm² (12 AWG).



Note:

The total current of the outgoing circuits must not exceed the nominal current of the step-down jumper/push-in type jumper bar.

Subject to changes. Please also observe the further product documentation!